Customizing Your Lexus

Your vehicle includes a variety of electronic features that can be personalized to your preferences. Programming these preferences requires specialized equipment and may be performed by an authorized Lexus dealership.

Some function settings are changed simultaneously with other functions being customized. Contact your Lexus dealer for further details.

Item	Function	Default setting	Customized setting
Smart access system with push-button start	Operation signal (Emergency flashers)	On	Off
	Operation signal (Buzzer)	On	Off
Wireless remote control	Unlocking operation	Driver's door unlocked in one step, all doors unlocked in two steps	All doors unlocked in one step
	Automatic door lock function to be activated if door is not opened after being unlocked	On	Off
	Time elapsed before automatic door lock function is activated if door is not opened after being unlocked	60 seconds	30 seconds
			120 seconds
	Operation signal (Emergency flashers)	On	Off
	Operation signal (Buzzer)	On	Off
	Door lock buzzer	On	Off
	Trunk unlocking function	On	Off
	Trunk unlocking operation	Push and hold	Push twice
			One short push
	Panic function	On	Off

<table>
<tr><th>Item</th><th>Function</th><th>Default setting</th><th>Customized setting</th></tr>
<tr><td rowspan="7">Door lock</td><td>Unlocking using a key</td><td>Driver's door unlocked in one step, all doors unlocked in two steps</td><td>All doors unlocked in one step</td></tr>
<tr><td>Speed-detecting automatic door lock function (Manual transmissions)</td><td>On</td><td>Off</td></tr>
<tr><td>Speed-detecting automatic door lock function (Automatic transmissions)</td><td>Off</td><td>On</td></tr>
<tr><td>Opening driver's door unlocks all doors (Manual transmissions)</td><td>On</td><td>Off</td></tr>
<tr><td>Opening driver's door unlocks all doors (Automatic transmissions)</td><td>Off</td><td>On</td></tr>
<tr><td>Shifting gears to P unlocks all doors</td><td>On</td><td>Off</td></tr>
<tr><td>Shifting gears to position other than P locks all doors</td><td>On</td><td>Off</td></tr>
<tr><td>Steering wheel</td><td>Auto tilt-away function</td><td>On</td><td>Off</td></tr>
<tr><td rowspan="4">Power windows</td><td rowspan="3">Linked door key operation</td><td rowspan="3">Open and close</td><td>Off</td></tr>
<tr><td>Open only</td></tr>
<tr><td>Close only</td></tr>
<tr><td>Wireless remote control linked operation</td><td>Off</td><td>Open only</td></tr>
<tr><td rowspan="6">Moon roof</td><td rowspan="3">Linked door key operation</td><td rowspan="3">Open and close</td><td>Off</td></tr>
<tr><td>Open only</td></tr>
<tr><td>Close only</td></tr>
<tr><td>Linked operation of components when door key is used</td><td>Slide only</td><td>Tilt only</td></tr>
<tr><td>Wireless remote control linked operation</td><td>Off</td><td>Open only</td></tr>
<tr><td>Linked operation of components when wireless remote control is used</td><td>Slide only</td><td>Tilt only</td></tr>
</table>

Item	Function	Default setting	Customized setting
Automatic light control system	Light sensor sensitivity	Level 3	Level 1 to 5
	Time elapsed before headlights automatically turn off after doors are closed	30 seconds	0 seconds
			60 seconds
			90 seconds
Lights	Daytime running light system (U.S.A. only)	On	Off
Windshield wipers and washer	Switching operation when the vehicle is stationary	On	Off
	Drip prevention function	On	Off
	Time elapsed before the drip prevention function operates	Variable depending on the vehicle speed	3 seconds
Intuitive parking assist	Back sensor operation display and buzzer	On	Off
	Buzzer volume	Level 3	Level 1 to 5
	Distance which a sensor detects	4.9 ft. (150 cm)	2.0 ft. (60 cm)
Illumination	Time elapsed before lights turn off	15 seconds	7.5 seconds
			30 seconds
	Operation when the doors are unlocked	On	Off
	Operation after the “ENGINE START STOP” switch turned OFF	On	Off
	Front footwell lights	On	Off
	Shift lever light	On	Off
	Outer foot lights	On	Off
Seat belt reminder	Vehicle speed linked seat belt reminder buzzer	On	Off

Your Lexus dealer

Your Lexus dealer will provide quality maintenance and any other assistance you may require.

If there is not a Lexus dealer near you, please call the following number:

- **U.S. OWNERS**
  - In the U.S. mainland or Canada:
    Lexus Roadside Assistance
    1-800-25-LEXUS or 1-800-255-3987 (Toll-Free)
  - In Hawaii:
    Servco Automotive Roadside Assistance/Customer Services
    1-800-25-LEXUS or 1-800-255-3987 (Toll-Free)
- **CANADIAN OWNERS**
  - In Canada or the U.S. mainland:
    Lexus Roadside Assistance/Customer Service
    1-800-26-LEXUS or 1-800-265-3987 (Toll-Free)

Please access our **websites** for further information.

- The U.S. mainland: **www.lexus.com**
- Hawaii: **www.servcolexus.com**
- Canada: **www.lexus.ca**